

YOLOv11 Training in Google Colab - Explained Code

Name : Shehryar Khan

Mount Google Drive

```
from google.colab import drive  
drive.mount('/content/drive')
```

Explanation: *Mounts your Google Drive to access files from within Google Colab.*

Define Paths

```
zip_file_path_in_drive = "/content/drive/My  
Drive/Colab_Datasets/archive (3).zip"  
destination_path_in_colab = "/content/archive.zip"
```

Explanation: *Defines the original zip file path in Google Drive and sets a simplified path for use in Colab.*

Copy ZIP File

```
!cp "{zip_file_path_in_drive}" "{destination_path_in_colab}"
```

Explanation: *Copies the zip file from Google Drive to Colab's working directory.*

Remove Old Folder (Optional)

```
!rm -rf /content/BrainTumor
```

Explanation: *Deletes any previous extracted dataset to prevent conflicts.*

Unzip Dataset

```
!unzip -o -q "{destination_path_in_colab}" -d "/content/"
```

Explanation: *Extracts the dataset zip file into Colab's working directory.*

List Directory Contents

```
!ls /content
```

Explanation: *Lists all files and directories in /content to verify dataset extraction.*

Import YOLO and OS

```
from ultralytics import YOLO  
import os
```

Explanation: *Imports the YOLO model class and Python's os module.*

Set Path to YAML File

```
data_yaml_path =  
"/content/BrainTumor/BrainTumorYolov11/data.yaml"
```

Explanation: *Defines the path to your dataset's configuration file (data.yaml).*

Verify YAML File Exists

```
if os.path.exists(data_yaml_path):  
    print(f"The file '{data_yaml_path}' exists in Colab.")  
else:  
    raise FileNotFoundError(f"Error: The file '{data_yaml_path}' does  
    not exist in Colab.")
```

Explanation: *Checks if the data.yaml file exists to prevent training errors.*

Load YOLOv11 Model

```
model = YOLO("yolo11n.pt")
```

Explanation: *Loads the pre-trained YOLOv11n model. Make sure the model file is available.*

Start Model Training

```
print("Starting training...")  
trained_model = model.train(  
    data=data_yaml_path,  
    epochs=18,  
    imgsz=640,  
    batch=16,  
    device=0  
)
```

Explanation: *Begins training the model with specified settings (epochs, image size, batch size, and device).*

Training Completion Message

```
print("Training finished.")
```

Explanation: *Indicates that the training process has finished.*

Output

Validating runs/detect/train/weights/best.pt...

Ultralytics 8.3.113  Python-3.11.12 torch-2.6.0+cu124 CUDA:0 (Tesla T4, 15095MiB)

YOLO11n summary (fused): 100 layers, 2,582,737 parameters, 0 gradients, 6.3 GFLOPs

Class	Images	Instances	Box(P	R	mAP50	mAP50-95): 100%
all	612	612	0.884	0.868	0.917	0.695
glioma	285	285	0.824	0.722	0.823	0.548
meningioma	142	142	0.926	0.963	0.97	0.8
pituitary	185	185	0.903	0.919	0.957	0.736

Speed: 0.3ms preprocess, 2.4ms inference, 0.0ms loss, 2.8ms postprocess per image

Results saved to runs/detect/train

Training finished.